# **Controller connection**

First connect phase wires and halls as shown on schematic.

Connect also battery supply and throttle, brake is optional.

At first power up controller will start automatically.

For navigation use middle buttons, to enter or edit parameter - right button, exit or undo change - left button.

After you finish setup do not forget to **Save settings**! Otherwise old settings will be loaded at next startup.

# **Auto-setup**

Fast setup for throttle, brake and motor.

Select required controller from device-list and go to directory **Auto-setup**.

If you have connected throttle and analogue brake, you can run **Full setup** and follow instructions shown on screen. The corresponding lines will indicate when it is necessary to press the throttle or brake.

ATTENTION! When setting up halls, motor rotates in both directions, be careful with the pedals on the bike.

If you have only throttle, you need to turn on every parameter manually step-by-step: Throttle, **Motor, Angle correction**. When you enable, after apply, hint will be displayed.

Before auto-setup it is recommended to specify correct pole pair number in motor parameters!

If motor heavy and auto-setup does not happen, you can increase **Setup current**, for example twice. If motor spins in wrong direction you can change any two phases or in **Motor setup** change **Spin** direction.

Motor will spin 5 times, one at motor detection and 4 times at angle correction.

# **Updates and settings**

**Import config.** - loads configuration from file NCconf.cfg/NCconf2.cfg/NCconf3.cfg... up to 9 different configurations can be saved.

**Export config.** - saves current controller configuration to file NCconf.cfg/NCconf2.cfg/NCconf3.cfg... up to 9 different configurations can be saved.

**Reboot** - reboots controller. If controller settings wasn't saved, it will load last saved configuration.

**Reset Wh usage** - resets consumed Watt-hours in controller.

**Reset stats** - resets trip distance.

Load defaults - loads default settings but doesn't save them, if you restart controller without save it will load last saved configuration.

Erase data storage - sometimes needed after update, in case when controller doesn't saves new configuration.

**Update firmware** - starts firmware update (firmware).

×

# **Control modes**

Last update: 2020/10/01 12:49

In section **Controller - Control modes** you can save three modes of motor operation and select these with 3-position switch or with display buttons.

If you don't have switch, mode 1 used by default. If your switch connected to display, you need to setup Display buttons.

At line # **Selected mode:** you can see currently active mode.

- N neutral
- S1 speed 1
- S2 speed 2
- S3 speed 3
- RV reverse

# **Modes setup**

To configure 2nd mode:

- Phase 2 maximum phase current.
- Battery 2 maximum battery current.
- Speed 2 maximum speed.

**Battery n** parameter have a boost mode, which allows you to briefly exceed the battery current settings specified in the Battery setup.

Boost is activated when the battery current exceeds the setting in the Battery setup.

Boost is activated for 5 seconds, followed by a minute cooling.

The next boost can be used when the active value of the battery current drops to the average value specified in the battery current settings.

Parameter **Speed n** determines the speed % depending on the reference speed setting (check speed setup).

When speed set over 100% it activates field weakening mode, that lets you to increase motor speed more than supply voltage (but not more than 95V of hardware limit), check Field weakening setup.

In general, it is recommended to setup the value of the phase current in 1.5-2 times higher than the battery current.

The rest of the presets are configured in the same way.

## Electric brake setup

**Braking phase** - specify phase current for braking.

You can also activate **Active braking** in menu **Control** to make motor stop at 0 speed.

If you are using switch brake, lower brake current change speed makes it more smooth.

Braking phase at speed control

Lets you to decrease speed when you release a throttle.

Works only with direct drive motors, without clutch.

**Braking ph. at speed** = setup phase current of braking when you need to limit speed.

Also to use this mode, should be selected:

- Control Throttle mode = Speed or Speed+torque
- **Control Speed lim. at 0% throttle** = (optional) enable if you need braking with completely released throttle.

Reverse setup

It is activated by a separate button, in the settings you must specify **Speed reverse** and **Phase reverse**.

Field weakening setup

The function is similar to the 120% mode of Infineon controller.

## Setup:

- For one of modes specify **Speed** more than 100%, for example **Speed 3** = 120%
- Field weakening specify weakening current, you can start with 30A

Field weakening is turned on when the maximum speed is reached, the controller adds the weakening current, limited to the specified phase current and the weakening current. If the phase current = 70A, the weakening current is 30A, than it means that in the settings of the phase current there should be at least 100A. If the phase current increases to 80A, then only 20A will remain for weakening, since 80A + 20A = 100A.

Also, controller will limit the rotational speed of the motor so that its effective EMF does not exceed the maximum supply voltage of the controller (not the battery). If the motor started to twitch on the free wheel, then it is necessary to reduce the weakening current.

### Current change speed

Three parameters that determine the rate of current change (smoothness). The higher the value, the faster the current will increase in the motor.

For conventional brake levers, it is useful to reduce the parameter **- braking** for smoother activation of regenerative braking.

If the response to the throttle seems too slow, you need to increase the parameter - **acceleration**. The - **shutdown** parameter determines how quickly the current drops after throttle and brakes are released.

Advanced control modes

# **Controller - Advanced modes**

In this menu you can activate advanced control modes with parameter **Enable adv. modes**.

**Neutral by default** - activates neutral mode at controller startup till one of speed modes is activated. Recommended to use with speed buttons (not switch). Doesn't work with 3 position switch setup (S1of3 and S3of3 port setup). In neutral mode throttle and PAS disabled, only brake works.

Every speed mode (S1, S2, S3) have it's own menu with these parameters:

- Throttle mode check setup throttle mode
- Acceleration lim. and Deceleration lim. (ERPM/s) allows you to limit speed of
  acceleration/deceleration, useful on slippery surface. To setup value go to menu Status flags,
  there is two parameters that saves maximum real acceleration and deceleration, Reset status
  flags and make a ride to check current values of acceleration. You can use these values as
  reference and decrease if you need to limit change speed.
- Reverse activates reverse mode.
- **Cruise** enables signal of cruise activation, useful with combination of cruise mode **Allow throttle hold** to enable cruise by throttle only on certain modes.
- **Disable motor** completely disables motor control.
- **Disable throttle** disables throttle control.
- Disable PAS disable Pedal Assist.
- Active braking allow brake to use battery for stopping.
- Speed lim. at 0% throttle allow to limit speed when throttle completely released.

#### Control

#### **Controller - Control**

In this section you can setup control sources for motor, like: throttle, Torque and PAS sensors, cruise control and etc...

#### Control source

You can connect controls to controller or display. Or even both, in the same time, this is necessary in the case of configurations Torque / PAS sensor + throttle.

- **Auto** all sources will control the controller. Built-in and external, connected via CAN bus (eg display).
- **Embedd** only what is connected directly to the controller.
- Remote only control via CAN bus.
- **Disabled** disables any control of the controller.

Throttle control mode setup

### There are 3 possible **Throttle modes**:

- **Speed** as in Infineon controllers and non-programmable low-cost controllers, characterized by using the maximum current to reach a given speed
- Torque throttle controls phase current
- **Speed+torque** combined mode, as Kelly

In the case of **Speed+torque**, pressing throttle to 50%, when achieved 50% speed, the current

https://docs.nucular.tech/

consumption will be reduced to hold speed.

The acceleration current will also be proportionally lower.

Throttle and brake voltage range setup

Currently, voltage settings for all throttles and brakes are common.

# Throttle - shows the voltage of throttle connected to the controller.

**Throttle min**, **Throttle max** - range of the throttle. When exceeding max. value by 5% - protection against a broken throttle will be activated.

# Brake - shows the voltage of brake connected to the controller.

**Brake min**, **Brake max** - range of analogue brake.

**Invert brake** - inverts the voltage value from the built-in brake. It can be useful to turn it on when a brake handle with reverse voltage is connected to the display, but you want to use **Auto** control source.

The digital brake handle (i.e. button) can be connected to the display, check Display buttons setup.

Active braking - allow brake to use battery for stopping.

**Brake at overheat** - allow full torque braking when motor overheated.

Cruise control setup

There are several cruise modes, determined by the parameter **Cruise**.

- **Button** at button press. The response time of the button is determined by the parameter **Cruise EN time**.
- **Switch** when the switch is turned on, time is not used.
- **Throttle hold** when you hold throttle a certain time in one position. The response time is determined by the parameter **Cruise EN time**. Accuracy is set by parameter **Cruise by throttle**. Accuracy is necessary because when driving, throttle moves a little because of shaking. The default is 2%.
- **Allow Throttle hold** similar to the previous one, with the difference that in order to activate cruise, you also need to turn on cruise switch.

Cruise level - selects what speed cruise will use:

- Throttle cruise speed depends on throttle position
- **Speed** cruise enables when **Safe acceleration** reached, after that uses current speed as reference.
- **Mixed** if controller cant use speed reference, uses throttle value.

**Safe acceleration** - limits acceleration speed where cruise can be enabled.

If the cruise button is connected to the screen, then you need to configure it in Display buttons.

What turns off cruise control:

- Any brake press, analog or digital
- Repeated throttle press
- If a switch is used when it's disabled.

Last update: 2020/10/01 12:49

• Reverse enable

Setup 100% speed value

# **Speed mode** lets you to choose how 100% speed works:

- OFF completely disables speed control PID
- Middle U bat average value from min/max battery voltage used as speed reference, depending on motor kV.
- **U supply** supply voltage used as speed reference, depending on motor kV.
- **Ref. speed** speed in kph, should be set with parameter **Reference speed**, speed value taken from motor speed or speed sensor connected to controller.
- Ref. ERPM speed in motor electric RPM, should be set with parameter Reference speed

# **Speed ref. filter** - selects the filter mode.

For the throttle modes **Speed** and **Speed+torque** a speed reference filter is applied, for a smoother response to the throttle change.

The filter takes a difference between the previous speed request and the current one, multiplies the error to the power 1,2,3 (linear, quadratic, cubic respectively) and multiplies by the coefficient. The resulting value is used as the cutoff frequency of the low pass filter. The greater the change - the faster the response to it.

Filter factor - sets the filtration coefficient

• **Speed lim. at 0% throttle** - allow to limit speed when throttle completely released. If disabled - speed control disables when throttle released.

## PAS setup

PAS connected to controller port P1/P2. (one or two-wire)

PAS unlike Torque sensor controls the throttle by frequency and not the rotational force.

#### Section Controller - Control - Pedal Assist Sensor:

**PAS** = Disabled\PAS sensor\Torque sensor

**PAS connection** = 1-wire\2-wire (for encoder mode use 2-w)

**Invert PAS** - changes the right direction for a 2-wire connection

PAS poles - number of pulses per pedal revolution

**PAS min freq.** - the minimum pedal speed at which the motor will be activated

PAS max freq. - the maximum pedal speed at which the motor will be activated for 100%

# PAS freq. - shows PAS speed in real time

PAS timeout - the time after which the motor is turned off after stopping the rotation of the pedals

**PAS filter** - smooths control signal for smoother operation

PAS min out - minimum control level when PAS is running

**PAS max out** - maximum level of control. By analogy with the "pressed" throttle, PAS sends a signal within the specified limits.

Next settings related to the pressure sensor (Torque sensor)

**Pressure scale** - Nm/V. You can calibrate by placing a load on the pedal and calculate the torque on the shaft through the lever.

Zero pressure - zero pressure in volts

**Torque averaging** - period for which is torque value updated. Measured in half turns. If the torque sensor measures only one pedal, then the period must be a multiple of two.

# Torque - shows the current torque at the sensor

# Human watt - shows pedaling power, averaged.

**Human watt min** - minimal human power for motor activation.

Human watt max - maximum level for 100% activation.

**Instant Torque** - allows torque sensor activation without rotation.

The pressure sensor also includes frequency configuration and output level configuration as well as the usual PAS.

Motor setup

Motor to-sensor

# Section Controller - Motor setup - Motor to-sensor

You can select a temperature range in which a smooth power limit will occur (parameter **Delta** °t) and specify °t max. It is recommended to install temperature sensor so close as possible on the stator windings, while not in contact with the stator iron. If you do not know what kind of sensor is in the motor, you can check all the options and choose the one that most closely to room temperature. Measured temperature is shown below. You can choose from sensors **KTY81(82)**, **KTY83**, **KTY84**, **NTC10K** (**B:3950**), **NTC10K** (**B:3380**), **PT1000**. To turn off temperature control, select **OFF** 

Clutch

# Section Controller - Motor setup - Clutch

Here you can set up a smooth motor start for soft engagement of the clutch or freewheel. Useful for gear motors or mid-drives.

Currently it works well only in the throttle mode **Torque**, since clutch there is always engaged. Another way is to setup acceleration limit on motor in advanced modes.

The parameter **Mode** determines the way of operation:

- Accelerate smoothly accelerates the motor until the load appears
- **Accelerate and hold** in addition to the previous one, it applies weak torque to the motor after the throttle is released, this mode allows you to switch speeds at mid-drive systems without using the pedals.

Start time - maximum time for soft start

**Start current** - is the phase current of the motor at which the load will be detected and the soft start is disabled. This value must be higher than the phase current for specified acceleration of the motor without load.

**Detection time** - the time during which the load must be present, after which the soft start will be switched off.

**Acceleration** - value in volts/seconds. The higher the value, the more you need to specify **Start current**, since the motor will consume more current during acceleration.

**Hold 20-80%** - two parameters regulating the phase current supplied to the motor in the mode **Accelerate and hold**. 20% - current at low speeds, 80% - current at about-maximum speed. It is possible to determine the approximate values by the no-load current of the motor.

Last update: 2020/10/01 12:49

**Hold enable time** - after how much time after the throttle has been pressed, torque hold will become available.

**Hold time** - how long torque will be applied after releasing the throttle.

TIP: Optimal setup for MAC motor: **Accelerate**, 15A, 50V/s, 200ms.

Manual angle setup

In this section you can manually change hall sensor angle.

**Offset for square** - additional shift for square wave mode.

**Offset total fwd** - shift all halls by the specified value for the direct rotation of the motor.

**Offset total bkwd** - shift all halls by the specified value for the reverse rotation of the motor.

To shift all halls, press enter, enter the angle of shift, press enter again.

The value will reset and the angle of all halls will change to the specified value.

You can change the angle of the hall in the opposite direction, setting a negative value.

**Reset angles** - clears all hall angles.

Integration threshold - analogue of the halls angles for the sensorless control mode.

Hall table

Here hall index and angles are specified for forward and backward direction.

Motor parameters

**Pole pair** - used to calculate RPM and speed. For more accurate auto-detection of angles, you need to specify the correct value, you can see in motor information table.

**Spin direction** - you can change the direction of rotation by default. Or swap two phases.

**Integration threshold** - analogue of the halls angles for the sensorless control mode.

Control mode - currently the controller has the following motor control modes:

- Square
- **Sensorless** motor control using BEMF integration, parameter **Integration threshold** is used. It is rather insensitive to tuning, but more accurate tuning may be required for high speed motors (such as RC). At the moment, the sensorless does not have a start-up algorithm, it works stably only at some speed. Hall setups starts with sensorless mode.
- **Combined** start on the halls, then switch to the sensorless, the threshold is determined by the parameter **From hall to s-less** (1 rad / ms = 9549 erpm)
- FOC field oriented control
- **Hz** 3Φ square with fixed frequency
- Sine Hz 3Φ sine with fixed frequency

Parameter **Control mode** loaded at start-up and can be saved.

Parameter **Control mode now** switches the control in real time, it is not saved.

**Interpolate halls** - smooth change of the hall angle based on speed. Used for FOC mode **Interpolation start** - the motor is always started from a discrete angle, if digital halls are used. After the specified speed, the angle starts to change smoothly.

**Boost square current**, **Boost current** and **Boost speed** - in the sensorless or square mode, applies 100% PWM at the beginning of each windings switch. Starting from specified speed and minimum requested current.

**Max motor U** - limits voltage supplied to the motor. In most cases, this parameter is not needed. **kV** - electric revolutions per volt

**Battery** 

Section **Controller - Battery**, here you must specify the range of the supply voltage and current. **Full charge** - delta voltage relative to the maximum, at which when the controller is turns on, will reset the watt-hour consumption

**Supply min-max V** - battery voltage range. Also used for Converter mode. For a lithium ion, it can be considered a minimum = 2.8V\*S, a maximum of 4.2V\*S. For LiFePO4 minimum 2.5V\*S, maximum 3.6V\*S.

**Charge max** - maximum battery charging current, during regeneration or in Converter mode. **Discharge max** - maximum continuous discharge current of the battery, but in boost mode it can be more, check Throttle control mode setup.

#### Converter

Section **Controller - Converter**. Here you can configure charging mode from the power supply through the motor. Charging through the inductor is not currently supported.

**Enable** - turn on the converter mode and starts charging.

**Auto-Enable** - automatic start of charging when the charging PSU is connected to the controller **Detection threshold** - minimum voltage on phases when charger mode activates, also disables motor control.

**Battery max I** - if no value is specified, then battery settings are used, maximum battery current.

**Battery min I** - minimum charge current when current decreased by voltage.

**Undercharge** - voltage relative to maximum battery voltage setup, lets you to decrease full charge voltage.

**Current drop delta** - decreases charging current down to **Battery min I** as the battery reaches maximum voltage on specified voltage range.

**Supply max I.** - maximum power supply current

**Supply drop U** - allowable voltage drop on wires or power supply

**Max motor t°** - limits motor temperature during charge.

Below # shows the real time values of voltages and currents.

I/O port configuration

Controller have 8 digital inputs that can be configured for many functions. Also available 8 CAN ports, signal source for that can be display or other device.

In menu **Port state** you can check input activation when contact shorted to GND.

**Speeds mode** - selects speed S1/S2/S3 switch mode - with buttons or switches (button mode have latch logic while switch mode should always have input active).

Available port functions:

- OFF disable port
- **RV** reverse
- CR cruise
- BK brake button
- DM disable motor (disable throttle, brake and PAS)
- **DTH** disable throttle
- **DPAS** disable PAS
- **SWSNS** input for gearsensor to reduce motor torque (WIP).
- **N** forces neutral mode, resets speed mode counter if used. If neutral by default activated you need to change speed mode again to exit neutral.
- nBK inverted brake button input
- **S1** speed 1
- **S2** speed 2
- **S3** speed 3
- S1of3 speed 1 for 3x position switch
- **S3of3** speed 3 for 3x position switch
- Scyc cycle speed mode
- S++ increment speed
- **S** - decrement speed
- SPSNS input for external speed sensor
- Spec. special port function (like PWM or PAS)

# Setup PWM output

To activate pwm output port **P1** or **P2** should be set to **Spec.** mode and PAS disabled.

P1/P2 ports work in open-collector mode, max 5V.

PWM freq - you can choose the frequency of additional PWM output on ports P1 / P2

**PWM Pn** - chooses mode of operation:

- Stop-light activated when the brake is pressed
- Headlight activated when the controller enabled
- t° C motor activated beyond the two deltas of the motor temperature, as the motor heats up will increase the PWM duty
- t° C controller activated from 40°C, maximum value at 80°C temperature of the controller

**PWM Pn Min/Max** - indicates the output range of the PWM (duty)

Extra parameters

#### Section Controller- Extra parameters.

Disable button and auto shutdown

Controller turns on when it is powers-up or the button contacts shorts.

There is a button in the display on the back, so an additional switch is usually not required. In disabled mode, the controller consumes less than  $100 \, \mu A$ , so if you reconnect the power without discharging capacitors, controller may not start again.

https://docs.nucular.tech/

# **Disable button** selects enable-disable mode:

- None controller turns on when it is powers-up or the button contacts shorts
- Switch controller turns on when EN shorted to GND, disables when contacts open
- Button controller turns on when enable pressed for 2 sec, repeat press to disable
- **CAN** controller turns on when it is powers-up or the button contacts shorts, disables only when other device on CAN bus will send request to disable. Used when there is a several controllers on a system, where one of them set to button or switch mode, and other in CAN mode.

**Auto shutdown** and **Sleep time** specify the time after which the controller will turn off if the motor does not spin.

**Lock at turn-on** - locks controller inputs when enabled untill you enter a password on display, if there is no display this will lead to constant lock.

Speed calculation

**Speed calculation** - this device will calculate the speed, useful for multi-motor configurations, you can turn off the speed calculation on some motors.

Circle length - circumference of the wheel.

**Motor sprocket** - setup gear ratio from motor shaft to wheel, also useful for gear motors.

Wheel sprocket - look above ^

If you have a hub-motor, then you need to setup motor pole-pair.

For gear motors or mid-drives, it is recommended to install an external speed sensor that is connected to the display.

Other

**Master-controller** - for multi-motor configuration one controller can be used as control source, if throttle/brake/etc.. connected to this controller.

**Device ID** - device number on LEVCAN bus

**Limit t° CPU** - maximum CPU temperature, limits phase current.

PID regulators

If you do not know what it is and why, it is better not to change it.

**Square** - phase current regulator for square wave.

FOC - phase current regulator for FOC mode

**DCv** - voltage regulator on the dc bus

DCi - dc bus current regulator

Speed - speed regulator for throttle modes Speed and Speed+torque

**PLL** - speed regulator for motor angle interpolation

Additional Information

Section Controller - Debug information shows temperatures, RPM, voltages and currents, as well

Last update: 2020/10/01 12:49

as regulator values.

Section **Controller - Status flags** displays errors that may occur during operation.

Section **Controller - Device information** can show you the version of the firmware and bootloader as well as the maximum parameters for this model of controller and it's lifetime statistics.

From:

https://docs.nucular.tech/ - Nucular Electronics

Permanent link:

https://docs.nucular.tech/doku.php?id=controller:setup&rev=1601549379

Last update: 2020/10/01 12:49