2024/04/28 01:13 1/4 Firmware

Copy files to root directory of microSD card (filesystem FAT32), insert into On-board computer (contacts on top) and run the update process.



Do not downgrade firmware that was installed by the manufacturer! You may get a brick

Each device has its own firmware and is updated separately from different menus. The order in which the firmware is updated does not matter.

- 1. Description of the On-Board Computer update menu.
- 2. Description of the Controller update menu.
- 3. Description of the uLight controller update menu.

To check the current firmware version, go to the **Device Information** menu, each device has a separate menu.

1https://docs.nucular.tech/doku.php?id=en:firmware&do=edit#sidebar-menu_trace. Information about the firmware version of the On-Board Computer.

- 2. Information about the firmware version of the Controller.
- 3. Information about the firmware version of the uLight controller.

The list of actual firmware to be downloaded: |Display |Controller |Release notes | |v0.60B



Fixed throttle drop.

Small menu fixes.

LEVCAN updated.

Button setup simplified, by default all set to CAN mode.

Added exFAT support (but display still can be updated only from FAT32).

Added charge screen.

Added fast statistics type selection.

Added wider event window.

Mph stats fixed.



Experimental logger added.

Fixed many charger glitches, however still have few.

Added soft start to charger and more safe phase detect.

Completely reworked field weakening, now should not have any hard braking after release.

Added minimum speed reference for speed PID.

Added RC PWM control on P1 port (throttle/brake).

Added more logger parameters.

Few important FOC control fixes, DC current should be calculated better under field weakening.

Fixed one weird ultra-rare bug in square mode.

LEVCAN operates on queues now, log time 2x faster when display updated.

Decreased DCi Ki default from 500 to 200.

Slightly decreased FW start point.

Last update: 2021/09/14 17:28

Added full debug info export.

Added logger mode selection and tuned logger start.

Removed first line from log for easy datazap upload.

Throttle / brake curves added (8 point configuration) with presets.

PAS extra scale added for additional modes.

Soft acceleration for cruise added, more shutdown triggers.

Cruise logic updated - phase current limited by selected mode, not throttle position.

Minimum cruise speed - limits cruise activation.

Cruise increment/decrement - control cruise speed with buttons (port = CR+/CR-)

Cruise restore - recovery last saved cruise speed with button, activated only above min cruise speed. (port = CRr)

Power limit added to modes and battery configuration. 0 = power limit disabled.

Small menu fixes.

CAN inputs increased to 16.

Parameters export / import fixes.

12V shutdown fix.

|31 August 2020

Use configuration export before update, reset defaults after update and import configuration. | |v0.59B



| |18 March 2020



HOTFIX for display speed sensor| |v0.58B

Fixed 0V throttle issue.

Fixed charge statistics reset.

Added kmh/mph switch.

Added more parameters to info. lines on main screen.

Added hotkey mode for compatibility with controller speed functions.

Fixed contrast setting.

Added driving range, calculated from WH usage.

A lot of tiny fixes.



Torque PAS fixes

Fixed configuration import for advanced modes

Added configuration selector from 1 to 9

Import will show first line of configuration, you can put a comment here

Fixed N mode

Fixed motor wiggle at charger mode

Added more debug information

|11 March 2020| | |v0.7.9 **1**|21 Nov 2019

https://docs.nucular.tech/ Printed on 2024/04/28 01:13

2024/04/28 01:13 3/4 Firmware

HOTFIX, fixed NaN error for analog inputs.| |v0.57B



CAN buttons setup Inverted inputs setup Statistics reworked Added filters for analog inputs



Big menu update

Control logic completely reworked for future compatibility with BMS

New default values for PIDs

DC-DC low voltage difference charge fixed

Inverted brake input added

Specific setup for 3 positional speed switch added (can work now as 1-2-3)

Button/switch select for usual speed select input

Save CRC calculation fixed

New speed mode - neutral

Speed increment and decrement added

Added t-sensor NTC 10k B:3380

Reboot command added

Fixed field weakening over 126%

Fixed VBUS measuring, now it is at PWM frequency, significantly improved overvoltage protection

Added median VBUS filter

Added averaging of N-X ADC samples filter for throttle and brake

Fixed brake glitches

Current measuring fixes for better measuring on 6F board

When enable button configured controller will not turn-on anymore when power applied

Autodetect improved, more informative, short-circuit detect added and timeout fixed

Added lock-at-turn-on, will lock throttle untill password on-screen is entered

Voltage on phases detect added, will lock controls

UVLO added

Added "Advanced modes" menu with more specific options per mode

Personal throttle protection lock for CAN source or local

Motor temperature limit for charger (DC-DC)

|20 Nov 2019

Export configuration (or make screenshots), after controller update do "Erase data storage" and reboot. Configuration will not be imported fully, some values will need to enter manually.

Last update: 2021/09/14 17:28

From:

https://docs.nucular.tech/ - Nucular Electronics

Permanent link:

https://docs.nucular.tech/doku.php?id=en:firmware&rev=1631633297

Last update: 2021/09/14 17:28

https://docs.nucular.tech/ Printed on 2024/04/28 01:13